

WIRED REMOTE CONTROL PANEL - MANUAL






Remote control panel

Communication line

The display panel can be operated remotely via a 6pin telephone line with a short distance of up to 7 meters.

Wired remote control panel with LCD display

battery voltage Inverter output voltage





- POWER 75

 Rattery Voltage

 Sattery Voltage


 Charging current AC Voltage

 25
- "ENERGY" means battery capacity percentage
- "POWER" means converting output power percentage
- "OVP" means over voltage protection
- "OTP" means over temperature protection
- "Normal" means inverter normal working

- "SCP" means short circuit protection
- "OLP" means over load protection
- "LVA" means low voltage alarm
- "LVP" means low voltage protection

Wiring diagram

Communication line diagram



Contact us